



22AIE313 Computer Vision & Image Understanding (2-1-3-4)

Dr. Aiswarya S Kumar
Dept. of Computer Science & Engineering (AI)
Amrita School of Computing

Camera Calibration

The image processing or computer vision field frequently uses the term “camera calibration.”

It is the process of determining specific camera parameters in order to complete operations with specified performance measurements.

This involves obtaining all the necessary information such as parameters or coefficients of the camera to establish an accurate relationship between a 3D point in the real world and its corresponding 2D projection in the image captured by the calibrated camera.

Camera Calibration

Types of Camera Calibration:

1. Intrinsic or Internal Parameters

It allows mapping between pixel coordinates and camera coordinates in the image frame. E.g. optical center, focal length, and radial distortion coefficients of the lens.


2. Extrinsic or External Parameters

It describes the orientation and location of the camera. This refers to the rotation and translation of the camera with respect to some world coordinate system.


Camera Calibration




The pinhole camera



The pinhole camera and mapping



3D to 2D mapping



3D to 2D mapping

$$\begin{bmatrix} X & Y & Z \end{bmatrix}^T \mapsto \begin{bmatrix} fX/Z & fY/Z \end{bmatrix}^T$$

(X,Y,Z) are the coordinates of a 3D point in the camera coordinate system.

(x,y) are the corresponding 2D coordinates on the image plane.

f is the focal length of the camera, which determines how far the image plane is from the pinhole (optical center).

The division by Z captures perspective projection, meaning objects further from the camera appear smaller.

Camera matrix

A camera is a mapping between the 3D world and a 2D image.

$$x = PX$$

2D image
point

camera
matrix

3D world
point

$$x = PX$$

$$\begin{bmatrix} X \\ Y \\ Z \end{bmatrix} = \begin{bmatrix} p_1 & p_2 & p_3 & p_4 \\ p_5 & p_6 & p_7 & p_8 \\ p_9 & p_{10} & p_{11} & p_{12} \end{bmatrix} \begin{bmatrix} X \\ Y \\ Z \\ 1 \end{bmatrix}$$

homogeneous
image
3 x 1

Camera
matrix
3 x 4

homogeneous
world point
4 x 1

Camera matrix

Camera matrix can be decomposed into two matrices

$$\mathbf{P} = \underbrace{\begin{bmatrix} f & 0 & p_x \\ 0 & f & p_y \\ 0 & 0 & 1 \end{bmatrix}}_{(3 \times 3)} \underbrace{\begin{bmatrix} 1 & 0 & 0 & | & 0 \\ 0 & 1 & 0 & | & 0 \\ 0 & 0 & 1 & | & 0 \end{bmatrix}}_{(3 \times 4)}$$

$$\mathbf{P} = \mathbf{K}[\mathbf{I}|\mathbf{0}]$$

Camera matrix

$$\mathbf{K} = \begin{bmatrix} f & 0 & p_x \\ 0 & f & p_y \\ 0 & 0 & 1 \end{bmatrix}$$

It contains intrinsic camera parameters such as focal length and principal point.

Focal length, f is the distance from the camera center to the image plane.

Principal point is the point where the optical axis (a straight line from the camera center perpendicular to the image plane) intersects the image plane.

Image Representation





| | | | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 157 | 153 | 174 | 168 | 150 | 152 | 129 | 151 | 172 | 161 | 155 | 156 |
| 155 | 182 | 163 | 74 | 75 | 62 | 33 | 17 | 110 | 210 | 180 | 154 |
| 180 | 180 | 50 | 14 | 34 | 6 | 10 | 33 | 48 | 106 | 159 | 181 |
| 206 | 109 | 5 | 124 | 131 | 111 | 120 | 204 | 166 | 15 | 56 | 180 |
| 194 | 68 | 137 | 251 | 237 | 239 | 239 | 228 | 227 | 87 | 71 | 201 |
| 172 | 106 | 207 | 233 | 233 | 214 | 220 | 239 | 228 | 98 | 74 | 206 |
| 188 | 88 | 179 | 209 | 185 | 215 | 211 | 158 | 139 | 75 | 20 | 169 |
| 189 | 97 | 165 | 84 | 10 | 168 | 134 | 11 | 31 | 62 | 22 | 148 |
| 199 | 168 | 191 | 193 | 158 | 227 | 178 | 143 | 182 | 106 | 36 | 190 |
| 205 | 174 | 155 | 252 | 236 | 231 | 149 | 178 | 228 | 43 | 95 | 234 |
| 190 | 216 | 116 | 149 | 236 | 187 | 86 | 150 | 79 | 38 | 218 | 241 |
| 190 | 224 | 147 | 108 | 227 | 210 | 127 | 102 | 36 | 101 | 255 | 224 |
| 190 | 214 | 173 | 66 | 103 | 143 | 96 | 90 | 2 | 109 | 249 | 215 |
| 187 | 196 | 235 | 75 | 1 | 81 | 47 | 0 | 6 | 217 | 255 | 211 |
| 183 | 202 | 237 | 145 | 0 | 0 | 12 | 108 | 200 | 138 | 243 | 236 |
| 195 | 206 | 123 | 207 | 177 | 121 | 123 | 200 | 175 | 13 | 96 | 218 |

| | | | | | | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| 157 | 153 | 174 | 168 | 150 | 152 | 129 | 151 | 172 | 161 | 155 | 156 |
| 155 | 182 | 163 | 74 | 75 | 62 | 33 | 17 | 110 | 210 | 180 | 154 |
| 180 | 180 | 50 | 14 | 34 | 6 | 10 | 33 | 48 | 106 | 159 | 181 |
| 206 | 109 | 5 | 124 | 131 | 111 | 120 | 204 | 166 | 15 | 56 | 180 |
| 194 | 68 | 137 | 251 | 237 | 239 | 239 | 228 | 227 | 87 | 71 | 201 |
| 172 | 106 | 207 | 233 | 233 | 214 | 220 | 239 | 228 | 98 | 74 | 206 |
| 188 | 88 | 179 | 209 | 185 | 215 | 211 | 158 | 139 | 75 | 20 | 169 |
| 189 | 97 | 165 | 84 | 10 | 168 | 134 | 11 | 31 | 62 | 22 | 148 |
| 199 | 168 | 191 | 193 | 158 | 227 | 178 | 143 | 182 | 106 | 36 | 190 |
| 205 | 174 | 155 | 252 | 236 | 231 | 149 | 178 | 228 | 43 | 95 | 234 |
| 190 | 216 | 116 | 149 | 236 | 187 | 86 | 150 | 79 | 38 | 218 | 241 |
| 190 | 224 | 147 | 108 | 227 | 210 | 127 | 102 | 36 | 101 | 255 | 224 |
| 190 | 214 | 173 | 66 | 103 | 143 | 96 | 90 | 2 | 109 | 249 | 215 |
| 187 | 196 | 235 | 75 | 1 | 81 | 47 | 0 | 6 | 217 | 255 | 211 |
| 183 | 202 | 237 | 145 | 0 | 0 | 12 | 108 | 200 | 138 | 243 | 236 |
| 195 | 206 | 123 | 207 | 177 | 121 | 123 | 200 | 175 | 13 | 96 | 218 |

RGB Representation


Arrays stacked over each other to form a Digital Image.



Bayer filter


A digital camera separates Red (R), Green (G), and Blue (B) components using **Bayer filter** (a color filter array) placed over the image sensor.

Each pixel only captures **one** color (R, G, or B).



Bayer filter

Bayer filter




Interpolation

Interpolation is a mathematical technique used to estimate unknown values between known data points.


Types of interpolation:

- Nearest-neighbour interpolation:
- Bilinear interpolation:
- Bicubic interpolation:


nearest neighbour




bilinear



bicubic





Edge Detection

Edges: Edges are abrupt changes in intensity, discontinuity in image brightness or contrast; usually edges occur on the boundary of two regions.




Figure: Original image (left) and edge (right)

Edge Detection

Edge detection: Edge detection is an image processing technique for finding the boundaries of objects within images. It works by detecting discontinuities in brightness.

Why we use edge detection?

- Reduce unnecessary information in the image while preserving the structure of the image.
- Extract important features of an image such as corners, lines, and curves.
- Edges provide strong visual clues that can help the recognition process.

Edge Detection

Here are some of the masks for edge detection.

- Prewitt Operator
- Sobel Operator
- Robinson Compass Masks
- Kirsch Compass Masks
- Laplacian Operator

Edge Detection

Prewitt Operator: By using Prewitt operator we can detect only horizontal and vertical edges.

| | | |
|----|---|---|
| -1 | 0 | 1 |
| -1 | 0 | 1 |
| -1 | 0 | 1 |

For Vertical Edges

| | | |
|----|----|----|
| -1 | -1 | -1 |
| 0 | 0 | 0 |
| 1 | 1 | 1 |

For Horizontal Edges

Edge Detection using Prewitt

| | | |
|--|--|--|
|  |  |  |
| Original Image | Applying Vertical Mask | Applying Horizontal Mask |

Edge Detection

Sobel Operator: The sobel operator is very similar to Prewitt operator. Like Prewitt operator sobel operator is also used to detect two kinds of edges in an image:

| | | |
|----|---|---|
| -1 | 0 | 1 |
| -2 | 0 | 2 |
| -1 | 0 | 1 |

For Vertical Edges

| | | |
|----|----|----|
| -1 | -2 | -1 |
| 0 | 0 | 0 |
| 1 | 2 | 1 |

For Horizontal Edges

Edge Detection

Robinson Compass Masks: A Robinson compass mask is a type of mask which is used for edge detection. It has eight orientations. It is also known as the direction mask. It extracts the edges with respect to its direction.

Following are its eight orientations:

North, North West, West, South West, South, South East, East, North East

| | | |
|----|----|---|
| 0 | 1 | 2 |
| -1 | 0 | 1 |
| -2 | -1 | 0 |

North West Mask

| | | |
|----|---|---|
| -1 | 0 | 1 |
| -2 | 0 | 2 |
| -1 | 0 | 1 |

North Mask

| | | |
|----|----|---|
| -2 | -1 | 0 |
| -1 | 0 | 1 |
| 0 | 1 | 2 |

North East Mask

| | | |
|----|----|----|
| 1 | 2 | 1 |
| 0 | 0 | 0 |
| -1 | -2 | -1 |

West Mask

Robinson Compass Masks

| | | |
|----|----|----|
| -1 | -2 | -1 |
| 0 | 0 | 0 |
| 1 | 2 | 1 |

East Mask

| | | |
|---|----|----|
| 2 | 1 | 0 |
| 1 | 0 | -1 |
| 0 | -1 | -2 |

South West Mask

| | | |
|---|---|----|
| 1 | 0 | -1 |
| 2 | 0 | -2 |
| 1 | 0 | -1 |

South Mask

| | | |
|---|----|----|
| 0 | -1 | -2 |
| 1 | 0 | -1 |
| 2 | 1 | 0 |

South East Mask



North West Direction Edges




North Direction Edges



North East Direction Edges



West Direction Edges



Original Image



East Direction Edges



South West Direction Edges



South Direction Edges



South East Direction Edges


You can take any mask and you have to rotate it to find edges in all the above mentioned directions.

Edge Detection

Kirsch Compass Masks:

This is also like Robinson compass find edges in all the eight directions of a compass.

The only difference between Robinson and kirsch compass masks is that in Kirsch we have a standard mask but in Kirsch we change the mask according to our own requirements.




Edge Detection

Laplacian Operator:

Laplacian is a second order derivative mask.

| | | |
|----|----|----|
| 0 | -1 | 0 |
| -1 | 4 | -1 |
| 0 | -1 | 0 |



Original Image



Image After applying positive Laplacian operator




Image After applying Negative Laplacian operator

Canny's Edge Detection

The Canny edge detection algorithm is a multi-step process that detects edges in images.

It's a popular algorithm in computer vision and is known for its effectiveness in detecting edges with minimal false detection.



Canny's Edge Detection

Gaussian smoothing


Smoothing reduces noise and prevents false edges.

Gaussian kernel,

$$G(x, y) = \frac{1}{\sqrt{2\pi\sigma^2}} e^{-\frac{x^2+y^2}{2\sigma^2}}$$

(x, y) is the pixel coordinate

σ controls the amount of blur



Canny's Edge Detection

1/16

| | | |
|---|---|---|
| 1 | 2 | 1 |
| 2 | 4 | 2 |
| 1 | 2 | 1 |

3x3 Kernel

1/273

| | | | | |
|---|----|----|----|---|
| 1 | 4 | 7 | 4 | 1 |
| 4 | 16 | 26 | 16 | 4 |
| 7 | 26 | 41 | 26 | 7 |
| 4 | 16 | 26 | 16 | 4 |
| 1 | 4 | 7 | 4 | 1 |

5x5 Kernel

1/1003

| | | | | | | |
|---|----|----|-----|----|----|---|
| 0 | 0 | 1 | 2 | 1 | 0 | 0 |
| 0 | 3 | 13 | 22 | 13 | 3 | 0 |
| 1 | 13 | 59 | 97 | 59 | 13 | 1 |
| 2 | 22 | 97 | 159 | 97 | 22 | 2 |
| 1 | 13 | 59 | 97 | 59 | 13 | 1 |
| 0 | 3 | 13 | 22 | 13 | 3 | 0 |
| 0 | 0 | 1 | 2 | 1 | 0 | 0 |

7x7 Kernel

Canny's Edge Detection

Finding gradients

Sobel finds the gradients in both horizontal and vertical direction. Since edges are perpendicular to the gradient direction, using these gradients we can find the edge gradient and direction for each pixel as:

$$G = \sqrt{G_x^2 + G_y^2}$$

Magnitude

$$\Theta = \text{atan}\left(\frac{G_y}{G_x}\right)$$

Direction

Canny's Edge Detection

Non-maximum suppression

This is an edge thinning technique. In this, for each pixel, we check if it is a local maximum in its neighborhood in the direction of gradient or not. If it is a local maximum it is retained as an edge pixel, otherwise suppressed.

For each pixel, the neighboring pixels are located in horizontal, vertical, and diagonal directions (0° , 45° , 90° , and 135°). Thus we need to round off the gradient direction at every pixel to one of these

After rounding, we will compare every pixel value against the two neighboring pixels in the gradient direction. If that pixel is a local maximum, it is retained as an edge pixel otherwise suppressed.

Canny's Edge Detection

Hysteresis Thresholding

Canny uses the Hysteresis thresholding to solve the problem of “which edges are really edges and which are not” . Here, we set two thresholds T_1 and T_2 .

Any edges with intensity greater than T_2 are the sure edges.

Any edges with intensity less than T_1 are sure to be non-edges.

The edges between T_1 and T_2 are classified as edges only if they are connected to a sure edge otherwise discarded.



(a) Original




(b) Smoothed




(c) Gradient magnitudes



(d) Edges after non-maximum suppression



(e) Double thresholding



(f) Final output



Thank you